



PRINTER PAT FACT SHEET

FITTING INSTRUCTIONS FOR REPLACEMENT MATT CHROME DAMPER

These steels have been treated and then gumed to ensure that they are hydrophilic (water receptive). Below are a number of suggestions for handling.

- Make sure that you wear rubber gloves as fingerprints leave an oleophilic (oil receptive) patch on the roller.
- When installing, ensure that the wrapping is covering the roller with only the fixing ends exposed.
- When installation is completed, re-etch and gum the steel with a suitable plate cleaner. This may need to be done several times to ensure that the roller becomes completely hydrophilic.

Please send return roller back in good condition.

NEED HELP

PRESS PARTS 0870 240 5815

Printer Pat online e-mail: Pat@pressparts.co.uk