



PRINTER PAT FACT SHEET

FITTING AND CARE OF PRINTGUARD PLUS

Thank you for purchasing PrintGuard Plus. There are three key features of PrintGuard Glass Bead Technology which eliminate marking:

Uniform glass bead diameter: Provides a uniform bead height at every point of contact with the wet printed sheet. This ultra smooth surface ensures the lowest coefficient of friction.

Dense glass bead matrix: Supports the printed sheet evenly and prevents ink buildup in the area between the glass beads. Glass bead surfaces are easy to clean and naturally repel ink buildup. Glass beads are resistant to solvents and oils and can withstand strong crushing forces making them extremely durable for the printing environment.

Monolayer: A perfectly level, low friction surface that guarantees equal support and release across the entire wet printed sheet width, thereby eliminating marking. The PrintGuard Plus jackets are easy to fit and will enhance the quality of your printing.

Mounting

PrintGuard Plus has a micro-cellular backing, which makes it unnecessary to pack behind the jacket.

Just clean the cylinder surface and put on the jacket. Jackets for the older style mounting system with the metal rods, are equipped with durable elastic loops for quick and easy installation. When fitting this type of jacket, ensure that the rubber loops are used at the rear edge!

Cleaning

In use there will be very little ink on the jacket. Any residue on the PrintGuard should be cleaned off with the mildest solvent available, preferably nothing stronger than white spirit.

NEED HELP

PRESS PARTS 0870 240 5815

Printer Pat online e-mail: pat@pressparts.co.uk